

Triple Trouble Clicker Tool manual



The Triple Trouble Clicker Tool is designed only for Beiter Recurve Clickers. Check out the clicker here: www.wernerbeiter.com/en/products/klicker/klicker.php

Our Clicker Tools come in a protected package. If you find any cracks, damages or other abnormalities upon unpacking. Please reach out to us (tripletrouble1440@gmail.com). You might be eligible for our warranty program.

Installing and using your Triple Trouble Clicker Tool*

1. Take your Clicker Tool
2. Place the Clicker Tool over the turning knob of your Beiter Clicker as shown in the picture below
3. Turn the Clicker Tool counter-clockwise to loosen your clicker
4. Move your Beiter Clicker to your desired position and tighten up the turning knob again using the Clicker Tool. Make sure to not use excessive force. This can break the Clicker Tool
5. Take your bow out and have fun!



**If there's anything not working properly, please reach out to us on tripletrouble1440@gmail.com.*